








Model Number

NJ5-18GM50-E2-3G-3D

Features

- 5 mm flush
- ATEX-approval for zone 2 and zone 22

Connection



Accessories


BF 18

Mounting flange, 18 mm

EXG-18

Quick mounting bracket with dead stop

Dimensions



0 mm

ected

Technical Data

General specifications					
	Switching element function		PNP	NO	
	Rated operating distance	s _n	5 mm		
	Installation		flush		
	Output polarity		DC		
	Assured operating distance	sa	0 4.05 m	m	
	Reduction factor r _{Al}		0.2		
	Reduction factor r _{Cu}		0.15		
	Reduction factor r ₃₀₄		0.62		

Nominal ratings

В		0 mm
С		15 mm
Operating voltage	U _B	10 60 V DC
Switching frequency	f	0 1500 Hz
Hysteresis	Н	1 15 typ. 6 %
Reverse polarity protected		reverse polarity protected
Short-circuit protection		pulsing
Voltage drop	U_d	≤ 3 V
Operating current	ΙL	0 200 mA
Lowest operating current	I _m	0 mA
Off-state current	I,	0 0.5 mA typ. 0.01 mA
No-load supply current	I ₀	≤ 9 mA
Indication of the switching state		LED, yellow

Functional safety related parameters

MTTF _d	1100 a
Mission Time (T _M)	20 a
Diagnostic Coverage (DC)	0 %
Ambient conditions	

Ambient temperature -25 ... 70 °C (-13 ... 158 °F) Storage temperature -40 ... 85 °C (-40 ... 185 °F)

Mechanical specifications

cable PVC , 2 m 0.5 mm² Connection type Core cross-section Housing material Stainless steel 1.4305 / AISI 303 Sensing face

Protection degree General information

Use in the hazardous area see instruction manuals 3G; 3D Category

Compliance with standards and directives

Standard conformity

Standards EN 60947-5-2:2007 IEC 60947-5-2:2007

Approvals and certificates

UL approval cULus Listed, General Purpose CSA approval cCSAus Listed, General Purpose

CCC approval Certified by China Compulsory Certification (CCC)

IP67



ATEX 3G (nA)

Instruction Manual electrical apparatus for hazardous areas

Device category 3G (nA) for use in hazardous areas with gas, vapour and mist

94/9/EG Directive conformity

Standard conformity EN 60079-0:2006, EN 60079-15:2005

Ignition protection category "n"
Use is restricted to the following stated conditions

 ϵ CE symbol

Ex-identification → II 3G Ex nA IIC T6 X

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Special conditions

Maintenance

Installation, Comissioning

The maximum permissible load current must be restricted to the values given in the following list. High load currents and load Maximum operating current IL

short-circuits are not permitted.

Maximum operating voltage U_{Bmax} The maximum permissible operating voltage UB max is restricted to the values in the following list. Tolerances are not per-

dependant of the load current I_L and the max. operating voltage U_{Bmax} .

Maximum permissible ambient tempera-

ture T_{Umax} at U_{Bmax} =60 V, I_{L} =200 mA

Information can be taken from the following list. 48 °C (118.4 °F) 52 °C (125.6 °F)

52 °C (125.6 °F)

at U_{Bmax} =60 V, I_{L} =100 mA at U_{Bmax} =30 V, I_{L} =200 mA Protection from mechanical danger

The sensor must not be exposed to ANY FORM of mechanical danger.

Protection from UV light

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor

is used in internal areas.

Electrostatic charging Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection cable must be prevented from being subjected to tension and torsional loading. Protection of the connection cable







ATEX 3D

Note This instruction is only valid for products according to EN 50281-1-1, valid until 30-September-2008

Note the ex-marking on the sensor or on the enclosed adhesive label

Manual electrical apparatus for hazardous areas Instruction

Device category 3D for use in hazardous areas with non-conducting combustible dust

94/9/FG Directive conformity Standard conformity EN 50281-1-1

Protection via housing Use is restricted to the following stated conditions

<€ CE symbol

Ex-identification → II 3D IP67 T 94 °C (201.2 °F) X

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. General

The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Special conditions

Maximum operating voltage U_{Bmax}

Maintenance

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list.

High load currents and load short-circuits are not permitted.

The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances

are not permitted.

dependant of the load current \boldsymbol{I}_{L} and the max. operating voltage \boldsymbol{U}_{Bmax} Maximum heating (Temperature rise)

Information can be taken from the following list. The maximum surface temperature at maximum ambient temperature is given in the Ex identification of the apparatus.

24 K at U_{Bmax} =60 V, I_{L} =200 mA at U_{Bmax} =60 V, I_{L} =100 mA 19 K at U_{Bmax} =30 V, I_{L} =200 mA 19 K

Protection from mechanical danger The sensor must not be mechanically damaged.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the Electrostatic charging

mechanical housing components can be avoided by incorporating these in the equipotential bonding.

Protection of the connection cable The connection cable must be prevented from being subjected to tension and torsional loading.



FPEPPERL+FUCHS

ATEX 3D (tD)

Note

This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004

Note the ex-marking on the sensor or on the enclosed adhesive label

Instruction Manual electrical apparatus for hazardous areas

Device category 3D for use in hazardous areas with combustible dust

Directive conformity 94/9/EG

Standard conformity EN 61241-0:2006, EN 61241-1:2004

Protection via housing "tD"

Use is restricted to the following stated conditions

CE symbol (ϵ

Ex-identification — II 3D Ex tD A22 IP67 T80°C X

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The maximum surface temperature has been determined in accordance with method A without a dust layer on the equip-

ment

The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be adhered to!

Repairs to these apparatus are not possible.

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

Maintenance No changes can be made to apparatus, which are operated in hazardous areas.

Special conditions

Maximum operating current I_L The maximum permissible load current must be restricted to the values given in the following list.

High load currents and load short-circuits are not permitted.

Maximum operating voltage U_{Bmax} The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances

are not permitted.

 $\label{eq:max-def} \mbox{Maximum permissible ambient temperature T_{Umax}}$

Protection of the connection cable

dependant of the load current I_L and the max. operating voltage U_{Bmax} .

Information can be taken from the following list.

Protection from mechanical danger

The sensor must not be exposed to ANY FORM of mechanical danger.

Protection from UV light The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor

is used in internal areas.

Electrostatic charging Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding. The connection cable must be prevented from being subjected to tension and torsional loading.

\\v\v\ TUBI

